



Room Power

ROOM ON

Touch screen to start

ROOM OFF

Select “POWER”

Confirm with “SHUT DOWN”

ALWAYS POWER ROOM OFF WHEN COMPLETE



In-Room PC

Select “Room PC” to use in-room computer



Laptop

Select “Laptop HDMI” or “Laptop VGA” to use your laptop



Connect laptop to VGA or HDMI cable located in the tabletop.

[If using VGA cable, also connect the 3.5mm audio jack]



Video Conference

Select “VC and Room PC” to display computer content over video conferencing call



Select “Video Conf” on the top bar to control video conferencing

Use keypad to dial number and **CONNECT** or **DISCONNECT** from call

Instructional Technology



e: pbci-isserviceDesk@email.arizona.edu



p: (602)827-4357 [opt.4]



Room Power

ROOM ON

Touch screen to start

ROOM OFF

Select “POWER”

Confirm with “SHUT DOWN”

ALWAYS POWER ROOM OFF WHEN COMPLETE



In-Room PC

Select “Room PC” to use in-room computer



Laptop

Select “Laptop HDMI” or “Laptop VGA” to use your laptop



Connect laptop to VGA or HDMI cable located in the tabletop.

[If using VGA cable, also connect the 3.5mm audio jack]



Video Conference

Select “VC and Room PC” to display computer content over video conferencing call



Select “Video Conf” on the top bar to control video conferencing

Use keypad to dial number and **CONNECT** or **DISCONNECT** from call

Instructional Technology



e: pbci-isserviceDesk@email.arizona.edu



p: (602)827-4357 [opt.4]